



5500G90 PRV 9i = Cartridge Sub-Assembly

- 1-5500G02-Gunmetal LG2 BS1400-Spring Chamber
- 2-5500G01-Gunmetal LG2 BS1400-Piston Chamber
- 3-5500G07-Gunmetal LG2 BS1400-Valve Bonnet
- 4-5500S06-Alum. Bronze CA104-Main Shaft
- 5-5300S06-Alum. Bronze CA104-Retaining Nut (Valve Disc)
- 6-5500G09-Gunmetal LG2 BS1400-Valve Disc
- 7-0002015-Nitrile-O Ring Valve Stem Seal
- 8-5300S10-Alum. Bronze CA104-Seal Retaining Washer
- 9-0002066-Nitrile-Renewable Valve Seal
- 10-5300S09-Alum. Bronze CA104-Nose End for Valve Disc
- 11-0005048-S/S 316(A2)-Retaining Screw
- 12-0003001-Carbon Steel-Inner Spring
- 13-5500S03-Alum. Bronze CA104-Piston
- 14-0002062-Nitrile-Quad Ring Piston to Piston Ch
- 15-0003003-S/S 316(A2)-Circlip
- 16-0002063-Nitrile-Quad Ring Shaft to Spring Ch
- 17-0002060-Nitrile-Quad Ring Shaft to Piston Ch
- 18-5500G08-Mn. Bronze CZ114-Shut Down spindle
- 19-5500G04-Mn. Bronze CZ114-Spring Adjustment Plate
- 20-5500G05-Mn. Bronze CZ114-Spring Adjustment Nut
- 21-0009001-Cast Iron-5" Dia Handwheel
- 22-0006002-S/S 316(A2)-M8 Plain Washer
- 23-0004004-S/S 316(A2)-M8 Nyloc Nut T Type
- 24-0002061-Nitrile-O Ring Shaft to Piston
- 25-0002064-Nitrile-O Ring Top Cover to Stem
- 26-0003002-Carbon Steel-Outer Spring
- 27-0005126-S/S 316(A2)-Clamp Screw
- 28-0002065-Nitrile-O Ring Top Cover/Spring Ch.
- 29-0002001-Nitrile-O Ring Spring Ch/Piston Ch
- 30-0002001-Nitrile-O Ring Piston Ch/ Valve Body
- 31-0002067-Nitrile-O Ring Valve Disc/Retaining Plate